

Pilot Assemblies

Part Number	Description	List price
01-3880-99	P1/PX1 Pilot Spool Assembly	
02-3880-99	P2/P200/PX200 Pilot Spool Assembly	
04-3880-99	P4/P8, PV4/PV8 Pilot Spool Assembly	
04-3882-99	P400/P800 Pilot Spool Assembly	
08-3885-99	PV810/PV1510 Pilot Spool Assembly	
15-3880-99	P15 Pilot Spool Assembly	
15-3882-99	P1500 Pilot Spool Assembly	
15-3884-99	PV15/PV1500 Pilot Spool Assembly	
00-3850-99-700	ASSY, PILOT SPOOL	